

*** How to operate Petitulux explained from Operating Video ***

#Turn button left for Up ,
Push down pole for down



#Turn button left.the main
panel can turn and pick it out .




Push electric button for use



5 light buttons can be chosen
respectfully.



MODE : CW (continuous wave)
RW(rotation wave)



WIND : FAN (wind continuous) /
AUTO (every 10 seconds off & on)



CW: 1~5 Lights (selected)
come out at the same time.
RW: 1~5 Lights (selected) is
rotated.

WIND : the WIND time setting
is set at the front panel time,
and the wind strength is fixed.

Caution 1: IR Light is invisible. But the mobile phone (Red Arrow) recognizes .

When IR Light is off.
Mobile Screen can't show it
on its screen.

When IR Light is on.
Mobile Screen can show it on
its screen.

